

# PSF-B04 Application Guide

## 1.Product Introduction

PSF-B04 is a 4-channel ultra-low-power Wi-Fi switch module based on ESP8285. It's specially designed for mobile devices and Internet of Things applications with the most competitive package size and ultra-low energy consumption technology in the industry. Connecting users' devices to the Wi-Fi wireless network for remote or local area network communication to achieve networking. This module can be used as a switch control for 4 household appliances. Either it can be controlled by the device button, or remotely controlled by connecting to APP (eWeLink).

PSF-B04 has various packaging methods, and the antenna supports ceramic antennas. It can be widely used in smart grid, smart transportation, smart home, handheld devices, industrial control and other fields.

Product Features:

- Built-in 32bit MCU, and can double as an application processor
- Support wireless 802.11 b/g/n standard
- Wi-Fi @2.4 GHz, support WPA/WPA2 security mode
- +20.5dBm maximum outputpower in 802.11b mode
- Support devicebutton control
- Support timer schedule
- Support Wi-Fi remote control
- Support compatible pairing mode /quickpairing mode
- Support OTA upgrade

## 2.Electrical Characteristics

### 2.1 Rated parameters

Conditions: VDD=3.3V±10% , GND=0V; test at room temperature 25°C.

Type	Parameters
Model	PSF-B04
Main chip	ESP8285
Hardware interface	UART, GPIO
Operating Voltage	2.7V~3.6V

GPIO drive capability	Max: 12mA
Working current	Average current: $\approx 80\text{mA}$ , Maximum working current: 210mA Standby: $< 200\mu\text{A}$
Operating temperature	0°C~45°C
Storage condition	Temperature: -10°C~75°C , Relative humidity: 20%RH~80%RH
Wireless network type	STA/AP/STA+AP
Encryption mechanism	WEP/WPA-PSK/WPA2-PSK
Encryption type	WEP64/WEP128/TKIP/AES
Firmware upgrade	OTA remote upgrade

## 2.2 Wi-Fi parameters

Conditions: VDD=3.3V $\pm$ 10% , GND=0V ; test at room temperature 25°C.


Type	Parameters
Wireless standard	IEEE 802.11b/g/n
Frequency range	2.412GHz-2.484GHz

Transmit power	802.11b: 20±2dBm (@11Mbps) 802.11g: 17±2dBm (@54Mbps) 802.11n: 14±2dBm (@HT 20, MCS 7)
Receiving sensitivity	802.11b: -91 dBm (@11 Mbps, CCK) 802.11g: -75 dBm (@54Mbps, OFDM) 802.11n: -72 dBm (MCS7)
Antenna type	Ceramic patch antenna

### 3. Module Type and Pin Definition

#### 3.1 Module type


PSF-B04 top view




#### 3.2 Sequence of pin arrangement

PSF-B04 module provides 4-channel switch control interface, Wi-Fi status light interface, UART serial port.

Top view of module pins:



Bottom view of module pins:



### 3.3. Pin definition

Pin definition and function description

Pin	Name	Features
1	ANT	Wi-Fi Antenna Note: PSF-B04 cannot be used
2	ADC	ADC interface, input range: 0-1V
3	EN	Chip enable terminal high level: valid; low level: closed. Note: An external pull-up resistor of 1~10K, connect a 100nF capacitor to the ground.
4	GPIO16	Main switch for 4-channel pin, active low. APP configuration pin, when the low level > 5S, enter the pairing mode.
5	GPIO14	The switch for the fourth channel pin, active low. APP configuration pin, when the low level > 5S, enter the pairing mode.

6	GPIO12	The relay switch for the first channel: active high, power-on default low level. Note: As a switch button, there will be a period of high level at the moment of power-on, which requires a pull-down (1~4.7K) resistor to ground.
7	STATUS	Wi-Fi status indicator light, connect LED in series with current limiting resistor to 3V3
8	GPIO15	The relay switch for the fourth channel, active low. APP configuration pin, when the low level > 5S, enter the pairing mode. Note: The chip configuration pin needs to pull down (1~4.7K) resistor to ground.
9	GPIO2	Used to program flash UART1_TX
10	GPIO0	The switch for the first channel, active low. APP configuration pin, when the low level > 5S, enter the pairing mode.
11	GPIO4	The relay switch for the third channel, active high, power-on default low level.
12	GND	GND
13	GPIO9	The switch for the second channel, active low. APP configuration pin, when the low level > 5S, enter the pairing mode.
14	GPIO10	The switch for the third channel, active low. APP configuration pin, when the low level > 5S, enter the pairing mode.
15	GPIO11	NC
16	GPIO6	NC

17	GPIO7	NC
18	GPIO8	NC
19	GPIO5	The relay switch for the second channel, active high, power-on default low level.
20	GND	GND
21	RX	Used to program flash UART_RX
22	TX	Used to program flash UART_TX
23	3V3	Power supply
24	RST	External reset signal: active at low level, externally need to pull up a 10K resistor to 3.3V, and connect a 100nF capacitor to ground.

## 4.Function Description

### 4.1. Module function

PSF-B04 module can be used as a 4-channel switch, which can control the switch locally or remotely through APP.

The following is the function description:

1. Pairingmethod: quick pairing mode / compatible pairing mode.  
Press and hold the button (IO0 pull-down, default high level) for more than 5s to enter the quick pairing mode. When it is in the quick pairing mode, press the button for more than 5s again to enter the compatible pairing mode. APP can be configured in both modes. Please refer to 4.3 for details of the configuration method.
2. Switch:
3. In the normal state: click the button (pull down any IO port of 4 channels for more than 100ms) to control the relay on and off (four relay switches corresponding IO port output high/low level)
4. In the pairing mode: click the button to exit the pairing mode.





3. No Server: The device has been connected to the router, but it cannot connect to the server (also known as "cannot access the Internet").
4. Unregistered: The device has not been bound to account. The device needs to be bound to the eWeLink account to connect to the cloud server. You can bind the device by tap "Add Device" in the eWeLink APP.
5. Upgrade: Indicates that the device is upgrading the firmware.
6. Setting G1: Indicates that the device is in compatible pairing mode. The device obtains the necessary information provided by the APP to join the service network, including router SSID, password, server IP, port number, etc in the setting mode.
7. Setting G2: Indicates that the device is in quick pairing mode. The device obtains the necessary information provided by the APP to join the service network, including router SSID, password, server IP, port number, etc in the setting mode. The device obtains information in different ways in the two modes, read below section for details.

### **4.3 The Wi-Fi module basic workflow**

1. Configuration
2. Compatible pairing mode: The mobile terminal joins the device AP as a station to form a local area network to realize data interaction. When the device is in the quick pairing mode (G state, see details in 4.2 Wi-Fi status indicator light description), press and hold the pairing button for 5S, the device enters the compatible pairing mode. Click "add device" on the eWeLink APP, connect the device hot spot in the phone setting page manually with SSID: ITEA 10000XXXX and password12345678 to connect the device to the Internet.
3. Quick pairing mode: The Wi-Fi module is in promiscuous mode, and the encrypted message containing information such as SSID and password from the mobile terminal is obtained by empty packet capture. The device enters the quick pairing mode by pressing the pairing button for 5S when it is in the A~D flashing modes. Click "add device" on the eWeLink APP, enter the SSID and password of the router to connect the device to the Internet.
4. Online  
The module goes through the following process from power-on to connecting to the server:
  1. Join the configured router and connect to the Internet.
  2. Connect to the server.
  3. Register the device and bind it to the eWeLink account.
  4. Obtain device application parameters and stay online.

When the connection/acquisition fails in the above steps, there are corresponding back-off strategies and reconnection mechanisms to ensure that the device is stable and keep online.

### 3. Upgrade

The module connects to the upgrade server, downloads and updates to the latest version of the firmware to realizes the online upgrade of the device.

### 4.4 Timer function

The timer function is configured through the APP, and the timer is divided into the following four types:

1. Single timer: execute at a specified time.
2. Count down timer: execute after the setting time.
3. Repeat timer: repeat the operation every week.

### 4.5 Timer function description

PSF-B04 supports timer. The eWeLink APP provides four timing modes to facilitate the use in more scenarios.

1. Single timer: This is the most common timing setting, allowing users to set the work schedule of the device. For example, turn on/off the device at 8:30 am every Wednesday, etc. It is similar to the setting of an alarm clock, timing is very convenient to use especially for devices that are repeatedly running at certain moments.
2. Count down timer: The count down is to facilitate the user to perform one-time timing operations, such as turn on/off the device after 30 minutes. It is very convenient to turn off a device after running a period of time. This device supports up to 24 hours of count down.
3. Repeat timer: Repeat the operation every week. For example, set an alarm clock for working time. After the time is set, select execute dates (a week optional), and the alarm clock will turn on at the set time within the selected days.

## 5. Wi-Fi Radio Frequency Index

Conditions: VDD=3.3V±10% , GND=0V ; test at room temperature 25°C.

Description	Minimum	Typical value	Max	Unit
Input frequency	2412	-	2484	MHz
Output impedance	-	50	-	Ω

Input reflection	-	-	-10	dB
PA output peak valuepower when at 72.2Mbps	15.5	16.5	17.5	dBm
PA output peak value power in 802.11b mode	19.5	20.5	21.5	dBm

### 5.1 Sensitivity

Description	Typical value	Unit mA
CCK 1Mbps	-98	dBm
CCK 11Mbps	-91	dBm
6Mbps(1/2BPSK)	-93	dBm
54 Mbps (3/4 64-QAM)	-75	dBm
HT20, MCS7 (65Mbps,72.2Mbps)	-72	dBm

### 5.2 Adjacent frequency suppression

Description	Typical value	Unit mA
OFDM, 6Mbps	37	dB

OFDM, 54Mbps	21	dB
HT20, MCS0	37	dB
HT20, MCS7	20	dB


Note:

1. 2Mbps is measured in the 802.11n mode, the MCS =7, the GI = 200uS.
2. Up to + 21.5dBm output power in 11b mode.

## 6.PCB Design

Precautions for PCB layout and module layout:


1. Pay attention to the placement of the module during PCB layout, especially the antenna part of the module, as far as possible away from interference sources: magnetic components (such as motors, inductance, transformers, etc.), high-frequency signal devices (such as crystal oscillators, high-frequency clock signals, etc.).
2. The upper and lower layers of the PCB where the module is placed should not be routed as much as possible. Do the copper-clad processing, and the PCB from the module antenna to the nearest pin of the module should be hollowed out as much as possible.
3. The module PCB antenna area and the 15 mm extension area need to be clear (copper, trace on the board, and component placement are strictly prohibited), refer to the following figure:



- Place the module's power supply (VCC) pin capacitance and other module pin capacitances, resistors as close as possible to the module pins, and the tracepath should be short.

### 7. Packaging Information

Package size diagram:



Share this: